

Intro to Instrumentation and Field Measurements in Remote Sensing

Javier Concha and Paul Romanczyk



Digital Imaging and Remote Sensing Lab
Chester F. Carlson Center for Imaging Science
Rochester Institute of Technology

January 8, 2015

Presented for 2015 Intersession Term

Outline

① Introduction

② Background

③ Taking Measurements

Outline

① Introduction

② Background

③ Taking Measurements

Course Goals

- Learn the importance of field measurements
- Learn how to take field measurements
- Learn about DIRS instruments

Course Description

- Friday: Introduction
- Monday: Introduction (con't) and DIRS instruments exhibition
- Tuesday: Lab: Reflectance measurements
- Wednesday: Lab: LIDAR measurements

Definitions

Field Measurements or Groundtruth:

“Observations or measurements made at or near the surface of the earth in support of remote sensing.”

Remote Sensing:

“Remote sensing is the science of obtaining information about objects or areas from a distance, typically from aircraft or satellites.”

Motivation

Why is it important?

- Validation
- Calibration
- Correction

Motivation Examples

R·I·T


Rochester Institute of Technology

Include:

- Javier's example (over water mea.)
- Paul's example (LIDAR and trees?)

Field Data Collection Area of Study

R·I·T Rochester Institute of Technology




Field Data Collection (con't)

Area of Study




Field Data Collection (con't)



Water Samples




Lab Analysis



Water Leaving
Reflectance



Spectroradiometer



Backscattering


Field Data Collection (con't)

Lab Measurements

R·I·T


Rochester Institute of Technology

Spectrophotometer



IOPs

Hydrolight



Filtration and Spectrophotometric Analysis



← Concentrations

Field Data Collection (con't)

2013 and 2014 Seasons

R·I·T Rochester Institute of Technology

		IOPs		Concentrations		Reflectances		Backscattering	
Date		Ponds	Lake	Ponds	Lake	Ponds	Lake	Ponds	Lake
2013	25-Aug	✓	✗	✓	✗	✗	✗	✗	✗
	19-Sep	✓	✓	✓	✓	✗	✓	✓	✓
	26-Sep	✓	✓	✓	✓	✗	✓	✗	✓
2014	17-May	✓	✗	✓	✗	✓	✗	✓	✗
	02-Jun	✗	✓	✗	✓	✗	✓	✗	✓
	11-Jul	✓	✓	✓	✓	✓	✓	✗	✓
	28-Aug	✗	✓	✗	✓	✗	✗	✗	✗
	29-Sep	✓	✓	✓	✓	✓	✓	✓	✓

Outline

① Introduction


② Background

③ Taking Measurements

Kind of Measurements

- reflectance
- concentration
- location

Radiometric Quantities: Radiance



ΔQ : radian energy
incident

Δt : time interval


ΔA : surface area at
location (x, y, z)

$\Delta\Omega$: solid angle in
direction (θ, φ)

$\Delta\lambda$: photons wavelength
interval

$$L(x, y, z, t, \theta, \varphi, \lambda) \equiv \frac{\Delta Q}{\Delta t \Delta A \Delta \Omega \Delta \lambda} \quad [Js^{-1} m^{-2} sr^{-1} nm^{-1}] \quad (1)$$

Radiometric Quantities: Radiance



ΔQ : radian energy incident

Δt : time interval


ΔA : surface area at location (x, y, z)

$\Delta\Omega$: solid angle in direction (θ, φ)

$\Delta\lambda$: photons wavelength interval

$$L(x, y, z, t, \theta, \varphi, \lambda) \equiv \frac{\partial^4 Q}{\partial t \partial A \partial \Omega \partial \lambda} \quad [Js^{-1} m^{-2} sr^{-1} nm^{-1}] \quad (1)$$

Radiance Sensor



(Source: [Mobley, 2010])

Radiometric Quantities: Irradiance

Spectral downwelling scalar irradiance at depth z :

$$E_{od}(z, \lambda) = \int_{2\pi_d} L(z, \theta, \varphi, \lambda) d\Omega \quad [Wm^{-2}nm^{-1}] \quad (2)$$

Spectral upwelling scalar irradiance at depth z :


$$E_{ou}(z, \lambda) = \int_{2\pi_u} L(z, \theta, \varphi, \lambda) d\Omega \quad [Wm^{-2}nm^{-1}] \quad (3)$$

Spectral scalar irradiance at depth z :

$$E_o(z, \lambda) \equiv E_{od}(z, \lambda) + E_{ou}(z, \lambda) \quad (4)$$

$$= \int_{4\pi} L(z, \theta, \varphi, \lambda) d\Omega \quad (5)$$

Scalar Irradiance Sensor



(Source: [Mobley, 2010])

Radiometric Quantities: Irradiance


Spectral downwelling plane irradiance at depth z :

$$E_d(z, \lambda) = \int_{2\pi_d} L(z, \theta, \varphi, \lambda) |\cos\theta| d\Omega \quad [Wm^{-2}nm^{-1}] \quad (6)$$

Photosynthetic available radiation, **PAR**:

$$PAR(z) \equiv \int_{350nm}^{700nm} \frac{\lambda}{hc} E_o(z, \lambda) d\lambda \quad [photons s^{-1}m^{-2}] \quad (7)$$

Planar Irradiance Sensor



(Source: [Mobley, 2010])

Reflectance

- Irradiance reflectance:

$$R(z, \lambda) \equiv \frac{E_u(z, \lambda)}{E_d(z, \lambda)} \quad (8)$$

- Remote sensing reflectance (water):

$$R_{rs}(\theta, \varphi, \lambda) \equiv \frac{L_w(\theta, \varphi, \lambda)}{E_d(\lambda)} \quad [sr^{-1}] \quad (9)$$

where L_w is the **water-leaving radiance**

- Bidirectional Reflectance Distribution Function (BRDF):

$$r_{BRDF} = \frac{L(\theta_o, \phi_o)}{E(\theta_i, \phi_i)} \quad [sr^{-1}] \quad (10)$$

Outline

① Introduction

② Background


③ Taking Measurements


Remote-Sensing Reflectance

- 3 measurements:
 - L_g (spectralon)
 - $L_t = L_r + L_w$ (water)
 - L_{sky}
- Remote-sensing reflectance:
$$R_{rs} = L_w/E_d$$
$$= (L_t - L_r)/E_d$$

with $L_r = 0.028 * L_{sky}$

 - $E_d = L_g * \pi$
 - ϕ : azimuthal angle
 - θ : zenith angle





Diffuse white reference panel (Spectralon)


R·I·T

Rochester Institute of Technology

- For a Lambertian surface:

$$L = \frac{E_d r}{\pi} \Rightarrow E_d = \frac{L\pi}{r}$$


- For spectralon $r \approx 1$
($\approx 100\%$)
 $\Rightarrow E_d = L\pi$



Thanks for your attention!


QUESTIONS?

Javier A. Concha
jxc4005@rit.edu



Thanks for your attention!
QUESTIONS?

Javier A. Concha
jxc4005@rit.edu



References



[[Mobley, 2010]

Ocean optics web book.

[http://www.oceanopticsbook.info/.](http://www.oceanopticsbook.info/)

]Mobley, C. D. (2010).